

Protection History Mode records and displays an event in which the THERMAL, CURRENT, ASO or DC protection was activated.



Procedure to enter the "Protection History Display Mode".

- 1. Press and hold the "SLEEP" and the "STATUS" buttons at the same time and press the "POWER" button to turn on the power.
- 2. Press the "STATUS" button again and the unit will display the Protection History condition.

CLEARING THE PROTECTION HISTORY



FLD Fluorescent Display

Caution: These protections may also be activated due to causes such as disconnection of connectors or operations around the microcomputer. When the **"STATUS"** button is pressed again after the above protection history as shown above is displayed, the normal display reappears.

Clearing the Protection History

If the unit is in "Protection History Display Mode", just press and hold the "iPOD" button for 3 seconds. Note: If you do not mind erasing your settings from this unit, you can also "Initialized/Micro Reset the unit to clear the Protection History from the unit's memory.

If the unit is not in "Protection History Display Mode", enter the "Protection History Display Mode":

- 1. Press and hold the "SLEEP" and the "STATUS" buttons at the same time and press the "POWER" button to turn on the power.
- 2. Press the "STATUS" button again and the unit will display the Protection History condition.



Warning Displays by POWER LED

If the power is turned off while a protection is detected, the POWER LED (red) flashes in the following ways as a warning according to the protection status.

- (1) ASO/DC protection: Flashes in 0.5-second cycles (0.25 seconds lit, 0.25 seconds unlit)
- (2) THERMAL (A/B) protection: Flashes in 2-second cycles (1 seconds lit, 1 seconds unlit)

MODEL INFO. INDEX

